

TEQCLEAN

Cleaning & Maintenance



PROFESSIONAL CLEANING FOR TEQPLAN

Teqton floors must, like all industrial coatings and floors, be maintained.

TEQCLEAN

The maintenance process consists of three phases, all aimed at improving durability, preventing soiling, optimizing dust binding, and ensuring that the floor maintains a presentable appearance:

Maintenance Requirements

1. Impregnation: Carried out to make the floor dirt-repellent and dust-binding.
2. Daily maintenance: Performed to remove dirt and, as far as possible, maintain continued dirt repellence and dust binding.
3. Deep cleaning: Carried out when continuous use and wear make it necessary.

Teqclean is used both for initial impregnation and for periodic cleaning and maintenance of Teqton floors.

Step 1 – Impregnation of a New Floor

- The Teqton floor must be thoroughly vacuumed, as the surface must be free of dust before impregnation begins.
- The floor is then washed using a mixture of 4 dl Teqclean to 10 litres of water.
- The cleaning solution is left on the floor as a water film and allowed to dry. This is best done using a combination machine/floor scrubber that can distribute the solution evenly across the entire floor. After a minimum of 30 minutes, any excess liquid can be removed using the machine.
- To fully saturate the floor, the above process should be repeated 2–3 times. The floor is then ready for daily use and cleaning.

Step 2 – Daily Cleaning

- Daily cleaning is carried out using a mixture of ½ – 1 dl Teqclean to 10 litres of water.
- Floor cleaning is best performed using a combination machine/floor scrubber fitted with a hard nylon brush.

TEQCLEAN

Cleaning & Maintenance



PROFESSIONAL CLEANING FOR TEQPLAN

Teqton floors must, like all industrial coatings and floors, be maintained.

TEQCLEAN

Step 3 – Deep Cleaning

- As required, a deep cleaning of the Teqton floor surface should be carried out. This is done to remove excess or accumulated maintenance film.
- The floor is washed using 5 dl Teqclean to 10 litres of water.

Deep cleaning is best performed using a machine with a hard nylon brush. Immediately after deep cleaning, the floor should be rinsed with clean water. The floor is then ready for continued daily cleaning.

Dosage Guidelines

- Impregnation: 4 dl Teqclean to 10 litres of water
- Daily cleaning: ½ dl Teqclean to 10 litres of water
- Deep cleaning: 5 dl Teqclean to 10 litres of water

Important

If the floor has been put into use prior to impregnation, a deep cleaning must be carried out first to ensure that all old dirt and soap residues are removed from the surface. The floor must then be impregnated.